

TOYOTA HILUX 2012 CLUB CAB

REAR SEAT DOUBLE SAFE

SAFE007

ENG

INSTALL TIME: 30mins

1 GET ORGANIZED you will need the following tools: a 4 mm allen wrench 10 mm flat wrench or socket wrench Here is what you are looking at:



Item #	Quantity	Description
1	1	DRIVERS SIDE SAFE
2	1	PASSENGER SIDE SAFE
3	8	M6 x 20 BUTTON HEAD BOLT
4	8	M6 NYLOC NUT
5	16	M6 x 19 x 1 FLAT WAHSER

IMPORTANT WARNING!

IT IS CRITICAL THAT ALL FRONT RUNNER RACKS AND ACCESSORIES BE PROPERLY AND SECURELY ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH TO YOU OR TO OTHERS. YOU ARE RESPONSIBLE FOR SECURING THE RACKS AND ACCESSORIES TO YOUR CAR, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR, AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS SUPPLIED WITH YOUR FRONT RUNNER PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER SUCH AS A QUALIFIED GARAGE OR AUTO BODY SHOP.

INSTALL SAFE

B)

Place the safe in position lining up the four holes in the safe with the four holes in the floor.

Insert a button head bolt (item 3) with a washer (item 5) into each of the holes.



D)

Lock the safe, remove the key and replace the removable floor panel.





C)

Place a flat washer over the end of the button head bolt from underneath followed by a nyloc nut (item 4).

Using a 10 mm wrench to stop the nyloc nut from turning, fasten the button head bolt from the top with a 4 mm allen wrench.



CHECK FOR OTHER COOL ACCESSORIES

Now's the time to take a trip to your dealer or visit www.**FRONTRUNNER.CO.ZA**

→ Modifying your vehicle involves some risks and may void certain aspects of your vehicle's warranty.

C 2011 Front Runner Outfitters, Inc.