
FRONT RUNNER

HI-LIFT JACK BRACKET



JADA010



READ ME!

Thank you for purchasing a Front Runner Hi-Lift Jack Bracket.

Before you start, take a moment to familiarize yourself with the Fitting Instructions and the components received.

Refer to Page 2 for a list of all the components, quantities and tools required.

IMPORTANT WARNING! /!\

IT IS CRITICAL THAT ALL FRONT RUNNER PRODUCTS BE PROPERLY AND SECURELY ASSEMBLED AND ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH. YOU ARE RESPONSIBLE FOR ASSEMBLING AND SECURING ALL FRONT RUNNER PRODUCTS TO YOUR VEHICLE, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND PRECAUTIONS SUPPLIED WITH YOUR FRONT RUNNER PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER OR OTHER QUALIFIED PERSONNEL.

NOTE: Front Runner will not be responsible for any damage caused by the failure to install the product according to these instructions.

Please call us if you have any questions about the installation of this product.




GET ORGANIZED

Here is what you are looking at for JADA010

IN THE BOX 1						
2 3 X M10x30x3 Flat Washer 3 4 X M8x25 Button Head Bolt (Black) 4 10 X M8x16x1.6 SS Flat Washer 5 1 X Base Bracket 6 1 X M10 Wing Nut 7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	۱	IN THE BOX				
3 4 X M8x25 Button Head Bolt (Black) 4 10 X M8x16x1.6 SS Flat Washer 5 1 X Base Bracket 6 1 X M10 Wing Nut 7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	1	1 X	M10x40 Hex Bolt		
4 10 X M8x16x1.6 SS Flat Washer 5 1 X Base Bracket 6 1 X M10 Wing Nut 7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	2	3 X	M10x30x3 Flat Washer		
5 1 X Base Bracket 6 1 X M10 Wing Nut 7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	3	4 X	M8x25 Button Head Bolt (Black)		
6 1 X M10 Wing Nut 7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	4	10 X	M8x16x1.6 SS Flat Washer		
7 1 X M12 Nyloc Nut 8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	5	1 X	Base Bracket		
8 1 X M12 Flat Washer 9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	6	1 X	M10 Wing Nut		
9 8 X M8 Nyloc Hex Nut 10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	7	1 X	M12 Nyloc Nut		
10 2 X M8x16 Button Head Bolt (Black) 11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	8	1 X	M12 Flat Washer		
11 1 X M12 Machined Stud 12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	9	8 X	M8 Nyloc Hex Nut		
12 2 X Support Bracket 13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	10	2 X	M8x16 Button Head Bolt (Black)		
13 1 X Handle Clamp Assembly 14 1 X M10 Tie Down Ring	I	11	1 X	M12 Machined Stud		
14 1 X M10 Tie Down Ring	I	12	2 X	Support Bracket		
· · · · · · · · · · · · · · · · ·	I	13	1 X	Handle Clamp Assembly		
15 2 X M8x30 Button Head Bolt (Black)	I	14	1 X	M10 Tie Down Ring		
	١	15	2 X	M8x30 Button Head Bolt (Black)		


IN THE BOX 16 2 X M8 Nut Cap 17 2 X M8 x 20 Hex Bolt







GET ORGANIZED CONTINUED





RECOMENDED POSITIONS


2.1

Please note that it is not recommended to mount your Hi-Lift Jack on the front or rear of your Rack only on the sides.


For ease of instruction, we have chosen to describe one orientation of mounting the Jack Bracket. The principals are the same, just the positioning and orientation of the brackets may vary depending on where you want to mount the jack.

Decide where on your Rack you would like to mount the Hi-Lift Jack. The brackets can be orientated upwards, downwards, front to back and back to front. Refer to Page 4, showing the various mounting options.







3 FIT AND SECURE




Fit and Secure Base Bracket in desired position as shown.



Secure as shown. Insert 2 M8 Hex Nuts at the point indicated by the arrow.



Assemble the machined pin and securing bolt in hole patern suited to your jack.



Fit and Secure the handle clamp in the desired position, using fasteners shown in Figure 1.2



FINISH

Congratulations! You did it. Take a step back and admire your work!



INSTALL OTHER VEHICLE AND RACK ACCESSORIES

Now's the time to visit your favorite Front Runner Dealer in person or online.

Be sure to tag us. We love to see our gear in action! #FrontRunnerOutfitters #BornToRoam

Share your adventures on:

() ()







